



NC-1200 Setup For QuickPos – Quick Setup Guide

Scan each barcode starting from the top.



Start configuration



Preamble



7



E



Confirm configuration



End configuration